



Channels import interval data for a meter.

An optional attribute of the channel configuration is the channel import ID. Some metering systems identify channel data with a channel import ID.

If a channel import ID is not available the meter import ID is used to match data with a meter. See the User Guide for more details.

Meter Import ID

- Is assigned to the meter.
- Used to import any channel data.
- Can be used multiple times with different channels.

Channel Import ID

- Is a unique ID assigned to a specific channel.